

INSTRUCTION MANUAL

PARAFFIN MACHINE

BEFORE THE DEVICE USE READ ALL THE SAFETY INSTRUCTIONS WITH ATTENTION. KEEP THIS MANUAL GUIDE SAFE FOR FUTURE REFERENCE.

INTRODUCTION:

The PARAFFIN MACHINE is used for the solid paraffin melting and heating for the professional hand- & feet care process.

OPERATION

Before the device use always check device and its accessories just state.

1. Unpack the device and its accessories from the packaging, than select and even surfaced, stable place for the device use.
2. Lift the lid than take out the accessories from the container bin, than wipe it out with a soft cloth.
3. Place back the safety grid into the bin bottom, than place in the necessary amount paraffin into the container bin. **Pay attention not to exceed the max. 2 Liter amount (2000ml). It is recommended to add the paraffin's in portions to the bin.**
4. Connect the device power cord into the outlet. The device indicator light will turn on with a green light.
5. Place back the lid, than set the front switcher into „H” position (High level = 70°C), when the paraffin is melted at least 70-75%, set back the switcher into „M” position (Medium level = app. 40°C). See more below at the USAGE chapter.
6. If you do not wish to use the device for a time being, set the front switcher into „L” position (Low level = it is used to keep the paraffin in a warm liquid state in low heat). Adjust the heat if you feel the paraffin temperature too low or too high.
7. After the device use is finished, set the front switcher to „OFF” position, than remove the device power cord from the outlet.

USAGE (on customer):

ATTENTION! The max. 70°C temperature („H” position) is not suitable for customer use. It is only used to start the paraffin melting process. It is recommended to start the melting process at 70°C („H”), than after 4-5min. when the paraffin app. 70-75% is melted set back the temperature to 40°C („M” position) Notice: the melting time and temperature can be different with the different type of paraffin's. If you notice the paraffin top is started to solidify or “skinning” raise the temperature with a few degree and if it is necessary stir the paraffin in the bin.

Before every customer use always check the paraffin correct temperature and always make sure of the customer skin- and nail conditions.

1. Remove all accessories from the customer hand/feet, than disinfect the customer limbs.
2. Apply suitable skin scrub for the customer skin surface, than when the process finished remove all the applied material from the skin surface, than wipe it dry.
3. Apply suitable nourishing cream into the customer hand/feet, than place the customer limbs into the container bin bottom. **Attention!** Before the customer use always check the paraffin correct temperature.
4. Take out the customer hand/feet from the paraffin, than wait for at least 10sec till the paraffin solidifies on the skin.
5. Repeat the previous step a few times (USAGE 4. chapter) than place the customer limbs separately into a waterproof foil or wrap. If it is necessary place the customer limbs together with the foil-wrap into a suitable textile glove or sock.
6. Wait for at least 10-20min, than remove all the solid paraffin with the foil-wrap from the customer limbs.
7. For the last step apply suitable nourishing cream to the customer skin surface.

MAINTENANCE & CLEANING:

Before the device cleaning always anneal it (see at OPERATION 7. chapter) and wait for the device cool down. It is recommended to wear gloves during the process.

Place the device into an even surfaced, stable pace. Remove the device lid than hold the container bin with both hands and pour out the lukewarm, liquid paraffin from the bin into a suitable waste container. Remove the security grit form the bottom, than wipe out all the remaining paraffin with a dry paper towel. Clean the container bin inside and outside with a lightly moist solvent-free detergent soft cloth or sponge, than wipe it dry. Clean the device remaining parts with a lightly moist soft cloth, than wipe it dry with soft paper towel. Apply solvent-free disinfectant to the bin inside, than wait for its full dry. Clean the security grid and the lid with the same method as the container bin, than wait for their full dry and place them back to their places. After the cleaning check the device correct operation.

Attention! Pay attention that the device cannot have any liquid inside in its switcher, joints or can become contacted with its power cord. At first apply the cleaning material into the cloth than start the process. Do not use solvent detergents. After the moist cleaning always wait for the device full dry and do not put it under in charge for at least 1-2min.

Clean the device and its accessories as it described above after every 3-4 customer use or if it is requires more frequently.

STORAGE:

After the device annealing (see at OPERATION 8. chapter), wait for its full cool down. Wind the power cord loosely together while pay attention not to break it. Store the device and its accessories in a dry place, far from radiant heat in clean state. **Before the device use always check device and its accessories just state.**

SAFETY CAUTIONS:

1. Only for indoor use, between 0~40°C (32~104°F)!
2. Before the device operation always make sure the device and its accessories just state.
3. Before every customer use always check the paraffin correct temperature and always make sure of the customer proper skin and nail health.
4. Use/store the device only in stable, even surfaced places. Do not put the device into places where it can be knocked down or may fall off.
5. The device cannot be left behind without supervision when it is turned on.
6. The device or its accessories cannot become contact with liquids.
7. Do not ever touch the device- or its accessories with wet/moist hands.
8. Do not ever operate the device if any parts of it are damaged or had any kind of accident or fell into water! Take the device into the place of purchase for repair and seek for professional help.
9. If you experience any unusual behavior e.g.: heat raise, smell etc. during in operation, stop the device use and look for the place of purchase and ask for professional help.
10. Only authorized personals can repair the device- or its accessories.
11. The device cannot have any irrelevant objects in its openings, joints or socket.
12. Use/store the device in a dry place far from radiant heat, in a clean environment. Avoid moist/wet and contaminated places.
13. The device can have electric charges in it even if it is turned off. After the device use is finished, always anneal it according to the OPERATION 8. chapter.

For more information about the device, visit our website: <http://www.brillbird.com/brillbird-distributors.html> or look for the place of purchase.

SPECIFICATION:

Input: AC 220-240V; 50Hz
Amperage: 0.5A
Weight: 1480g
Measure: 325*235*180mm

NOTICE! If any case of malfunction was found or any parts of the device has to be replaced or repaired, please contact with the dealer where the unit was purchased!

BRILLBIRD Europe LTD.; O u. 46, H-1066 Budapest, Hungary

KEZELÉSI ÚTMUTATÓ

PARAFFIN MACHINE

'LILA PARAFFIN GÉP'

A KÉSZÜLK HASZNÁLATA ELŐTT KÉRJÜK, OLVASSA EL FIGYELMESEN AZ ÖSSZES BIZTONSÁGRA VONATKOZÓ FIGYELMEZTETÉST.
ÓRÍZZE MEG HASZNÁLATI ÚTMUTATÓT BIZTONSÁGOS HELYEN, ÉPSÉGBEN KÉSÖBBI HASZNÁLAT ESÉTÉRE IS.

TERMÉK BEMUTATÁS:

A PARAFFIN MACHINE - Lila Paraffin Gép, a professzionális kéz- és lábápolásra szolgáló paraffin felmelegítésére szolgáló berendezés.

MŰKÖDTETÉS:

A Készülék üzembe helyezése előtt minden esetben ellenőrizze le a berendezés- és tartozékainak épp állapotát.

1. Vegye ki a berendezést- és tartozékeit a csomagolásból, majd válasszon egy stabil-, egyenletes felületet a készülék használatához.
2. Helyezze bele a szükséges mennyiségi paraffint a Készülékbe. **NE** lépje túl a max. 2liter!
3. Csatlakoztassa a készülék Hálózati vezetékét a konnektorba. A Zöld jelzőlámpa világítani fog.
4. Állítsa a készüléket „H” állásba, majd a paraffin min. 70-75%-os megolvadásánál vegye vissza 1 fokozattal „M” állásba.
5. Amennyiben a működtetés közben egy ideig nem kívánja használni a Készüléket, állítsa „L” állásba a kapcsolót. Az „L” funkció a paraffin melegen tartásra szolgál.
6. Kontrollálja a paraffin hőmérsékletét, és ha túl melegen érzi, hagyja egy kicsit hűlni.
7. A használat befejeztével, minden esetben kapcsolja ki a berendezést, majd húzza ki a hálózati vezetékét az aljzatból.

HASZNÁLAT VENDÉGEN:

FIGYELEM! Kezelésre NEM alkalmas a max. 70°C -os hőmérséklet, csak a paraffin megolvasztásához használható! Javasolt az olvasztást 70°C -on elkezdeni, majd 4-5 perc elteltével visszavenni a működési hőmérsékletet! A paraffin 70-75%-ának a felolvadása után állítsuk vissza a hőmérsékletet max. 40°C-ra („M” állásba) (ez az érték paraffin típusonként változhat, így amennyiben beindulna a felolvadt felszín bőrösödése, emeljük néhány fokkal a hőmérsékletet).

1. A Használat előtt távolítsa el minden ékszert és kiegészítőt a vendég kezéről/lábáról!
2. A Paraffin Machine – Lila paraffin Gép használata előtt, első lépésként alkalmazzon bőrradírt a vendégen! A használat után, távolítsa el maradéktalanul az alkalmazott anyagot, majd törölje szárazra a bőrfelületet.
3. Kenje be a vendég kezét/lábát ápoló krémmel, majd helyezze be a vendég kezét/lábát a felmelegített paraffinba. **Figyelem!** minden esetben ellenőrizze a paraffin megfelelő hőmérsékletét.
4. Emelje ki a vendég kezét/lábát a paraffinból, majd várjon 10 másodperct, amíg kissé megszilárdul az anyag a bőrfelületen.
5. Ismételje meg az előző lépést (HASZNÁLAT 4. pont) néhányszor, majd húzza bele a vendég kezét/lábát külön-külön egy vízhatlan fóliába.
6. Várjon 20percet, majd távolítsa el a megszilárdult paraffint a fóliával együtt a vendég végtagjairól.
7. Végezetül, kenje be az alkalmazott területet nyugtatón, ápoló krémmel.

KARBANTARTÁS&TISZTÍTÁS:

A Tisztítás/karbantartás előtt minden esetben áramtalanítsa a készüléket (kapcsolja ki a berendezést, majd távolítsa el a készülék hálózati vezetékét az aljzatból), ill. várja meg készülék teljes lehűrését! A tisztítás/karbantartás során ajánlott kesztyűt viselni.

A feszültségmentesítés után a készülék külső műanyag borítása puha nedves ruhával tisztítható. **NE** használunk oldószer tartalmú tisztítószeret! A készülék paraffin tartó részének tisztítása egyszerű. Vegyük le készülék fedelét, majd öntsük ki a langyos, folyékony paraffint a gépből. Töröljük ki a maradék paraffint száraz papírtörő segítségével, majd egy puha, nedves ruhával töröljük át a készülék belsejét. Tisztítás után várjuk meg, amíg teljesen megszáradd a készülék, illetve 1-2 percig **NE** helyezzük a feszültség alá! Ügyeljünk arra, hogy semmilyen folyadék **NEM** kerülhet vagy érintkezhet a készülék kapcsolóival, csatlakozóival vagy hálózati vezetékével!

TÁROLÁS:

Készüléket kikapcsolás után húzzuk ki a hálózati aljzatból, hagyjuk teljesen kihülni és száraz helyen, sugárzó hőtől távol tároljuk! Csakis tiszta állapotban tároljuk a készüléket! A kihúzott Hálózati kábelt csak lazán terekerjük össze vigyázva arra, hogy **NE** törjük meg! **A Készülék üzembe helyezése előtt minden esetben ellenőrizze le a berendezés, a tartozékok és a hálózati vezeték épp állapotát.**

BIZTONSÁGI ELŐIRÁSOK:

1. Csak beltéri körülmenyek között használható a készülék, 0-40°C között!
2. A Készülék üzembe helyezése előtt minden esetben ellenőrizze le a berendezés, a tartozékok és a hálózati vezeték épp állapotát.
3. Mindig stabil, egyenletes felületen használja a készüléket.
4. **NE** tegye a készüléket olyan helyre, ahol leverheti vagy leeshet!
5. A bekapcsolt készülék **NE** hagyható felügyelet nélkül!
6. Soha **NE** hozza működésbe a készüléket, hogyha bármely eleme/tartozéka sérült ill., bármely által rongálódott vagy vízbe esett!
7. **Azonnal állítsa le és áramtalanítsa a készüléket**, hogyha a nem a megszokott módon működik, ill. túlzott hőmérsékletelemelkedést tapasztal!
8. Vigye a készüléket a vásárlás helyszínére, hogy megvizsgálják és a szükséges javításokat elvégezzék!
9. Kizárálag, csak az illetékes személyek javíthatják a készüléket!
10. A készüléket száraz helyen, sugárzó hőtől távol kell tartani!
11. A készülék nyílásai, csatlakozói idegen tárgy **NE** kerülhet.
12. Semmilyen folyadék **NE** kerülhet vagy érintkezhet a készülék kapcsolóival, csatlakozóival vagy hálózati vezetékével!
13. Soha **NE** érjen vizes/nedves kézzel az áram alatt lévő készülékhez, annak kapcsolóihoz, csatlakozóihoz vagy hálózati vezetékéhez!
14. A készülék elektromos részei akkor is elektromos töltéssel rendelkeznek, ha kikapcsolt állapotban van. A munka végeztével **mindig** húzza ki a készülék hálózati vezetékét az aljzatból!

A készülékkel kapcsolatos bővebb információkért, látogasson el honlapunkra <http://www.brillbird.hu/mukorom-alapanyagok/mukormos-csiszolopep-uv-lampa> ill., szükség esetén keresse fel a vásárlás helyszínét vagy szervizünket.

MŰSZAKI JELLEMZŐK:

Bemeneti jellemzők: 220-240V; 50Hz

Áramerősség: 0.5A

Súly: 1480g

Méret: 325*235*180mm

FIGYELEM!

A készülék meghibásodása esetén, ill. bármely tartozékának cseréjéhez/javításához keresse fel a vásárlás helyszínét!

Brillbird Europe Kft.; 1066 Budapest, Ó utca 46.